

NITECORE®

KEEP INNOVATING

UA42Q User Manual



IMPORTANT NOTICE CONCERNING WARRANTY SERVICE


Thank you for purchasing! Before using this charger, please find your verification code on the package box, and go to <http://charger.nitecore.com/validation> (or scan the QR code beside the verification code to visit on your mobile phone). Type in your verification code and personal information as required, and submit the page. After verification, Nitecore will send you a warranty service email. This email and your registration email address are essential to your possible warranty application. Before you complete the warranty service registration, you cannot enjoy our warranty service for your purchase.

Specifications

Input: 100-240V~AC 50-60Hz 1A
Output: 5V --- 3A, 9V --- 2A, 12V --- 1.5A
36W MAX
Dimensions: 82mm×65mm×28.4mm (3.23"×2.56"×1.19")
(Plug Included)
Weight: 116g (4.09oz)

Operating Instructions

1. Plug in the UA42Q.
2. Connect the UA42Q to the external devices (smartphones, tablets or other USB devices) via the USB charging cable to begin charging.



Precautions

1. Ambient Temperature of Usage: -10~40°C (14~104°F); Temperature of Storage: -20~60°C (-4~140°F)
2. DO NOT expose the device to direct sunlight, heating devices, open flames, or rain and snow environment; avoid extreme high or extreme low ambient temperatures and sudden temperature changes.
3. Store the device in ventilated areas. DO NOT use the device in moist environment and keep away from any combustible materials.
4. Avoid any shock or impact to the device.
5. DO NOT disassemble or modify the device as doing so will render the product warranty invalid. Please refer to the warranty section in the manual for complete warranty information.
6. DO NOT misuse in any way! Use for intended purpose and function only.

Disclaimer

This product is globally insured by Ping An Insurance (Group) Company of China, Ltd. NITECORE shall not be held responsible or liable for any loss, damage or claim of any kind incurred as a result of the failure to obey the instructions provided in this user manual.

Warranty Details

Our authorized dealers and distributors are responsible for warranty service. Should any problem covered under warranty occurs, customers can contact their dealers or distributors in regards to their warranty claims, as long as the product was purchased from an authorized dealer or distributor. NITECORE's Warranty is provided only for products purchased from an authorized source. This applies to all NITECORE products. To be qualified for warranty, please refer to the "IMPORTANT WARRANTY NOTICE" section on top to validate your product. Any DOA / defective product can be exchanged for a replacement through a local distributor/dealer within the 15 days of purchase. After 15 days, all defective / malfunctioning NITECORE® products can be repaired free of charge for a period of 18 months from the date of purchase. Beyond 18 months, a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

The warranty is nullified if the product(s) is/are:

1. broken down, reconstructed and/or modified by unauthorized parties
2. damaged from wrong operations

For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or send an email to service@nitecore.com.

※ All images, text and statements specified herein this user manual are for reference purpose only. Should any discrepancy occur between this manual and information specified on www.nitecore.com, information on our official website shall prevail. SYSMAX Innovations Co., Ltd. reserves the rights to interpret and amend the content of this document at any time without prior notice.

SYSMAX Innovations Co., Ltd.

TEL: +86-20-83862000
FAX: +86-20-83882723
E-mail: info@nitecore.com
Web: www.nitecore.com
Address: Rm 2601-06, Central Tower, No.5 Xiancun Road, Tianhe District, Guangzhou, 510623, Guangdong, China
Manufacturer: SYSMAX Power Technology, LLC
Address: B4 Happy Factory, 81 East Huahong Commercial Street, North Zhenxing Road, Gaobu, Dongguan, China



Thanks for purchasing NITECORE!
Please find us on facebook: [nitecorecharger](https://www.facebook.com/nitecorecharger)

NITECORE® 奈特科尔

UA42Q 中文说明书



（简体中文）售后服务的重要提示


感谢您购买本产品！在使用本产品之前，请持包装上防伪码登录 <http://charger.nitecore.cn/validation> 或刮开防伪贴纸的二维码，用手机扫描前往验证页面，按页面提示填写防伪码及个人信息等资料。成功通过正品验证后，您将收到奈特科尔发来的保固凭证邮件。请牢记您的注册邮箱及保存售后服务邮件，此资料为该产品享受保固服务的重要凭证。如不进行售后服务申请，将不能享有该产品的保固服务。

参数

输入:	100-240V~AC 50-60Hz 1A
输出:	5V=3A, 9V=2A, 12V=1.5A
输出最大功率:	36W
尺寸:	82mm×65mm×28.4mm (包含插头部分) (3.23" ×2.56" ×1.19")
重量:	116g (4.09oz)

使用方法

- ① 连上电源
- ② USB 充电线一端连接 UA42Q，另一端连接手机、平板电脑或其他 USB 设备，即可进行充电。



注意事项

1. 本产品使用环境温度：-10-40°C (14~104 °F)，储藏温度：-20-60°C (-4~140 °F)。
2. 禁止将适配器暴露于明火或置于暴晒、雨雪环境中。避免在过高温、低温或温度骤变环境中使用。
3. 请将适配器置于通风处使用，切勿在潮湿的环境中使用或置放适配器。操作区域内不可放置易燃易爆物质。
4. 避免机械振动以及冲击，防止损坏适配器。
5. 切勿擅自拆卸、组装或改装适配器，可能会导致保修服务失效，详情请查看保固条款。
6. 不可将适配器作为他用！仅可将适配器用于指定用途。

免责声明

本产品由中国平安保险（集团）股份有限公司全球承保。因未按照本产品说明书指导正确操作而发生任何事故或意外所引起的损失或索赔，本公司不承担任何责任。

保固服务

NITECORE® 产品拥有售后保固服务。在购买本产品的 15 天内，如果有任何质量问题均可向经销商要求免费更换。在购买本产品的 18 个月内享受免费保固服务。在超过 18 个月免费保固期后，本产品享有终身有限度保固服务，如需要更换重要部件则需收取成本费用。

本保固规则不适用于以下情况：

1. 人为破坏，拆解，改装本产品。
2. 错误操作导致产品损坏。

如对奈特科尔产品有任何疑问，欢迎联系当地的代理商或发邮件到 4008869828@nitecore.cn

※ 本说明书的所有图片、陈述及文字信息仅供参考，请以官网 www.nitecore.cn 实际信息为准。广州希脉创新科技有限公司拥有对说明书内容的最终解释权 and 修改权。

广州希脉创新科技有限公司

咨询热线: +86-20-83862000

销售邮箱: info@nitecore.com

网 址: www.nitecore.cn

地 址: 中国广东省广州市天河区冼村路

5 号凯华国际中心 2601-06 室

邮 编: 510623

更多信息请关注新浪微博: NITECORE 奈特科尔

UA040442Q19

